

Reloading Part Programs From an Archive

1. Press **Menu Select** hardkey
2. Press **Services** horizontal softkey
3. Press **Data In** horizontal softkey
4. Using the arrow keys, move down to Part-programs (the target directory for the files being loaded)
5. Press **Enter**
6. Press **Archive** vertical softkey
7. Using the arrow keys, move down to the part program archive. It should be named PARTPRO##### with the last characters being the date. Use the newest file available
8. Press **Start** vertical softkey
9. Press **Yes All** on the vertical softkey to overwrite all files
10. Press **Delete Log** vertical softkey once complete

End of Procedure