

Creating NC Archives

Note: This procedure should be performed after any changes to Numeric Control data (parameter changes, User Data value changes, machine reference position adjusted, etc.)

1. Press **Menu Select** hardkey
2. Press **Services** horizontal softkey
3. Press **>** (lower right) horizontal softkey
4. Press **Series Startup** horizontal softkey
5. Using the arrow keys, move down to the check box next to NC
6. Press the space bar to place a check in the box. If the box is already checked, proceed to step 7
7. Repeat steps 5 & 6, using the space bar to **uncheck** all boxes except NC
8. Using the arrow keys, move down to the **Archive Name** box and input NC#####, using the current date at the end. Example NC052909
9. Press **Archive** vertical softkey

Note: This procedure creates an archive on your control's hard drive. To save a copy to an external source (which is **highly** recommended) refer to procedure OP-104-3400All-840DI-A-Copying Data from Control to External Sources.

End of Procedure